

Product Introduction Installation Guide Handlesets

EH.8668 EH.8669 EH.8688



Contents

Read before use

Product specifications	1
2 ³ / ₈ " & 2 ³ / ₄ " adjustable deadbolt	4
2 ³ / ₈ " & 2 ³ / ₄ " adjustable latch	4
Installation instructions EH.8668 (A) is a reference example	
Install exploded view	5
Installation steps	6

▲ Notice


Please read and understand all instructions before use:

- The warranty does not apply if damage is caused by failure to follow these instructions.
- Only alkaline batteries can be used, other batteries are not recommended.
- When cleaning the product, please wipe it with a soft cloth.
- When the battery power is low and the alarm occurs, please replace the battery in time to keep the battery power sufficient.
- * The "electronic main control module" of this product (please refer to the basic product introduction) is dust-proof and water-resistant; tested under controlled laboratory conditions, its effect reaches IP65 level; dustproof and water-resistant functions are not permanently effective.


Protective properties degrade due to daily wear and tear. Do not charge the smart lock (emergency power interface) when it is wet; damage caused by liquid entering the internal structure of the electronic lock is not covered by the warranty.

Product specifications

EH.8668 (A)



EH.8668 (B)




1


Read before use

Product specifications

EH.8669 (A)




EH.8669 (B)




Product specifications

EH.8688 (A)




EH.8688 (B)




❷ 2³/₈″/2³/₄″ adjustable deadbolt






Adjustment instruction of deadbolt When adjusting, rotate the "deadbolt" (as the picture).









- 2. Can be adjusted to two backsets 23/8" and 23/4". (as above picture).
- 3. After selecting the backset, return to the correct position of deadbolt.

√2³/8″/2³/4″ adjustable latch








Adjustment instructions of latch

- 1. Can be adjusted to two installation center distances: 23/8" and 23/4".
- 2. When adjusting, push the "adjustable square core" forward to $2^{3}/8''$ (Picture 1), and pull it backward to adjust to $2^{3}/4''$ (Picture 2).

Installation instructions (EH.8668 (A) is a reference example)

Install exploded view




NO.	Title	Quantity
1	Self-tapping screws	4PCS
2	Latch Bolt	1PC
3	Deadbolt	1PC
4	Front plate	1PC
5	Tube	1PC
6	Spring	1PC
7	Decorative cover	1PC


NO.	Title	Quantity
8	M5 screw	1PC
9	M4 screw (long)	2PCS
10	M4 screw (short)	3PCS
11	Base plate assembly	1PC
12	Battery cover	1PC
13	Battery cover	1PC


Installation instructions (EH.8668 (A) is a reference example)


Installation steps




1. Make holes in door "A" and "B" at 2-1/8", and for the Grip Handle bottom screw (per template).











Remove the battery cover


▲ Notice

For details, please refer to the <User manual>


Installation instructions (EH.8668 (A) is a reference example)

Installation steps









⚠ Notice

Battery installation for details, please refer to the <User manual>

▲ Notice

- 01. Please do not try to disassemble this product by yourself, otherwise you may get an electric shock or damage the product.
- 02. Do not use hard or heavy objects to knock this product.
- 03. When going out, please make sure the lock is locked before leaving.
- 04. Please be careful not to hit the handle to avoid injury.
- 05. Do not use any corrosive cleaners to clean this product, such as gasoline, products which contain alcohol, or other chemicals, etc., otherwise it will cause damage to the electronic circuit, product degradation, or paint peeling.
- 06. Please change your password regularly (about three months); when your password is leaked, please change your password in time; our company is not responsible for accidents caused by user negligence.
- 07. When using manual mode to lock, please be sure to confirm whether the door is closed and locked.
- 08. Do not use rechargeable batteries, only alkaline batteries are recommended.
- 09. Please be sure to follow the above instructions to avoid any injury or property damage.
- 10. The performance of this product cannot be guaranteed in special environments such as high-humidity weather and the seaside.